


“pseudo-random”, because each patch has an ID number and the random layout is precisely defined in terms of where each patch is located. The random layout can be recognized by the group of patches located in the middle of the target. These patches are identified below.



Note: The IT8.7/4 target is also used by IDEAlliance for printer and monitor proofing. However, since proofing requires **absolute** (i.e. device-independent) color values, IDEAlliance provides reference values for three standard paper types (GRACoL Coated-1, SWOP Coated-3 and SWOP Coated-5). In IDEAlliance files, each patch is characterized by the CMYK values of the standard plus the absolute L*a*b* values to be achieved on a specific paper. Please consult the PatchTool documentation and Application Notes 3 and 4 for more information on how to use the IT8.7/4 target for certification purposes.

1.2. When is there a problem with an IT8.7/4 measurement file?


Many IT8.7/4 files are saved with the patches in an order corresponding to the random or visual layout, but with improper IDs. This is quite common, even in reference files! The problem becomes more difficult to handle when the file was generated from measurements, and from a random layout, where the rows may have been scanned backwards, or where the rows were considered columns, and vice-versa. In these cases, the file data often looks garbled when first opening the file. Being unable to see the measurements in the visual layout makes it quite hard to judge the quality of the measurements and can even make the data useless for a profile creation program. Fortunately, in most cases, this can easily be fixed in PatchTool.

2. Using PatchTool to “fix” an IT8.7/4 measurement file

2.1. Example-1: A simple reassignment

If the opened file layout corresponds to the “visual” or “random” layout shown in the Introduction, you should check the ID of the first patch, in the upper-left. For a visual layout, the ID should be 171 (and CMYK = 0/100/20/0), while it should be ID 636 (and CMYK = 85/55/85/0) for the random layout. You may often find that the first patch has an ID of “1”, as shown below; this is a sure sign that all IDs are incorrectly assigned.

To correct the situation, use the “Re-map” popup menu to assign the IDs for the corresponding layout. Once this is done, you can reliably change the layout and export the data in a file which will be recognized by other applications. If the first patch ID is correct, you should also check a few of the key patches shown previously for each layout, but nothing prevents you of re-assigning the patches, just in case.



2.2. Example-2: A rotated target

In this second example, we have a file with measurements taken with a DTP70 scanning spectrophotometer controlled by the ColorPort software; the spectrophotometer and the measuring software are both from X-Rite. Here is a screenshot of the file where we see the file header plus the first data points.


```
CGATS.17
ORIGINATOR "X-Rite, Inc."
CREATED "2009/04/02"
FORMAT_VERSION 1
INSTRUMENTATION "X-Rite DTP70"
NUMBER_OF_FIELDS 44
WEIGHTING_FUNCTION "ILLUMINANT, D50"
WEIGHTING_FUNCTION "OBSERVER, 2 degree"
BEGIN_DATA_FORMAT
SAMPLE_ID CMYK_C CMYK_M CMYK_Y CMYK_K LAB_L LAB_A LAB_B SPECTRAL_380
END_DATA_FORMAT
NUMBER_OF_SETS 1617
BEGIN_DATA
1 100 100 0 47.82908 -67.80692 26.94498
2 0 100 70 29.74449 43.72973 28.98676
3 100 100 40 20 16.70583 20.3027 -35.01599 0.0796
4 20 30 55 0 79.81773 4.057869 18.77184
5 10 20 85 0 83.05572 -0.1398064 54.52559
6 40 0 2 3 27183 849879 14328
```


This is a well structured CGATS type file, with the Illuminant and Observer identified as per the CGATS.17 standard. However, we observe that the patch IDs, the first data column labeled “SAMPLE_ID” as per the CGATS standard, start at “1”, which indicates that some ID reassignment will be required. On the right, we see how the file appears in PatchTool when opened.

The first thing we notice is that the patches are not disposed in a full rectangular shape, either horizontally or vertically, where all columns are of the same length. We see that the “Row QTY” is “In file: floating”, which simply indicates that no values were found in the file for this quantity. CGATS file often have a “LGOROWLENGTH” tag which defines this value, but this tag is not part of the CGATS standard and is not used by all vendors.

In its standard horizontal layouts, an IT8.7/4 target has 33 rows and 49 columns (33 x 49 = 1617). We can change the number of rows by selecting one of the preset values in the “Row QTY” menu or by writing the value in the “Custom rows” field and pressing the *Return* key.

Since the target layout may be turned 90 degrees, we do not know yet if we should specify 33 or 49 rows. Let’s try both; the two layouts are shown on the next page.







While both layouts have no partially filled columns, the one with 49 rows has a group of patches in the middle which is characteristic of the random layout. We now need to decide what other changes we can do to see our file correspond to the standard random horizontal layout.

The next step is easier to perform if we have a known “good” image of a random IT8.7/4 layout to compare to. Without one we can still make informed decisions based on a few characteristic patches. We see below our opened file against the reference random layout. Apart from the key patches in the layout center, we notice that the green and brown patches of the first column in our opened file correspond to the last patches of the first row in the reference file.


Our reference IT8.7/4 random layout.



We need to turn our layout 90 degrees clockwise to make it correspond to the reference random layout.



From these observations, we can conclude that our file is turned 90 degrees relative to the reference layout. To turn the file layout, use the “Re-map” popup menu and select “Turn 90° CW” (90 degrees clockwise), as shown on the next page.



After the rotation, our file is now in the same layout as the reference random layout. As a last step, we need to assign the IDs for the random layout, also using the “Re-map” menu. From there, we can change to the visual layout and save our “fixed” file.

To wrap-up, here are the three steps we did to fix our file:

- i- Assign a custom “Row QTY” of 49 and look for key patches
- ii- Rotate the layout 90 degrees clockwise
- iii- Assign the IDs for the random layout

2.3. Example-3: A target with flipped rows and columns



This last example is from another measurement file. The measuring instrument and the software package are shown in the file header, shown just below. As in Example-2, the IDs start at “1”, and a reassignment is required. However, here we see that the LGOROWLENGTH tag is present and set to “49”. This is why, in the opened file, we see a full rectangular layout with all rows and columns of the same length.

```

IS12642
ORIGINATOR      "Profile-Xpert Gateway Version: 2.30, Specifi
DESCRIPTOR      "Output Characterisation"
CREATED         "October 9, 2007 14:01"
INSTRUMENTATION "Spectro Swing ver:3.73 RT"
MEASUREMENT_SOURCE "Illumination=D50 ObserverAngle=2°
ILLUMINANT      "D50"
OBSERVER        "2"
PRINT_CONDITIONS "No printer defined, No resolution defined,
NUMBER_OF_FIELDS 8
BEGIN_DATA_FORMAT
SAMPLE_ID       CMYK_C CMYK_M CMYK_Y CMYK_K LAB_L LAB_A
END_DATA_FORMAT
NUMBER_OF_SETS  1617
LGOROWLENGTH    49
BEGIN_DATA
1 85 55 85 0 47.835 -9.108 10.678
2 20 20 70 60 51.525 3.005 29.989
3 30 55 10 0 67.099 24.192 -8.373
4 0 20 70 40 70.521 5.158 40.149
5 0 25 0 0 86.105 9.644 -6.715
6 20 20 0 0 95 44.7 380

```

Our reference IT8.7/4 random layout.




While we can recognize the characteristic patches of a random layout in our opened file, they are not in their proper location. As well, the green and brown patches are at the bottom of the first column. This means that a simple rotation will not fix the layout. There are two methods we can use to realign this layout.

Method-1: Rotate 90 degrees and flip horizontally


Even if we know that a rotation will not fix the layout, let's do it nonetheless. Using the "Re-map" popup menu, we turn the layout 90 degrees **clockwise** (CW). Below, we see the rotated layout against the reference random layout.

Our reference IT8.7/4 random layout.



The layout after a 90 degrees clockwise rotation.

The next step is to flip the layout horizontally.




After the rotation, with both layouts horizontal, we realize that our file is a mirror image of the reference layout. We can fix this by flipping our file layout horizontally with the "Flip Horizontal" command of the "Re-map" menu.

As in Example-2, the last step is to assign the IDs for the random layout. This three steps procedure can be described as follow:

- i- Locate the key patches and rotate the layout 90 degrees clockwise
- ii- Flip the layout Horizontally
- iii- Assign the IDs for the random layout

Method-2: Flip rows and columns


If we compare closely the reference layout with our file, we see that the first reference row is the first file column; the second reference row is the second file column; and so on. This can also be observed in the key patches.



What we have here is not a simple rotation (we already know this since we did it as the first step in Method-1 of this example) but a substitution where rows and columns are interchanged. To arrange the layout, we should start with the first column, turn it 90 degrees counter-clockwise (CCW) so that it becomes our first row, then take the second column, turn it similarly, and place it **under** the first row, etc. This is quite a task to do manually, but it can be done in a single “Flip R/C” (i.e. Flip Row/Column) command of the “Re-map” popup menu.


The second and last step is to assign the IDs for the random layout. This procedure can be described as follow:

- i- Locate the key patches and flip the rows and columns
- ii- Assign the IDs for the random layout



As we mentioned in the introduction, being able to see the target in the visual layout can be helpful in assessing the quality of the data. Once the IDs are assigned, we can easily get the visual layout by selecting the “Change layout to IT8.7/4 Visual” command of the “Re-map” menu. This command will work even if we sort the data in the “Tabular data” or if we change a patch position in this table (by clicking and dragging one or more rows in the table for instance) since this re-ordering does not affect the IDs.

Here we show the Example-3 file in its visual layout. We can clearly see that the press from which the data came from is either not calibrated or has other problems which need to be addressed!



3. Conclusion

We saw three examples of how PatchTool can be used to fix an IT8.7/4 data file where the standard IT8.7/4 patch IDs have been mislabeled and where the file layout was shuffled by the measurement process. You can experiment with any combination of row quantity, rotation and flip, until the layout corresponds to your needs. If the results are not as expected, you can always reset all changes, using the “Re-map” menu, and try another approach.

The BabelColor Company

Founded in 2003, *The BabelColor Company* is dedicated to the development and sale of specialized color translation software and color tools. It also provides color consulting services for the professional and industrial markets.

info@BabelColor.com
<http://www.BabelColor.com>

BabelColor is a registered trademark, and the BabelColor logo is a trademark of Danny Pascale and The BabelColor Company.

“GRACoL” and “IDEAlliance” are registered trademarks of International Digital Enterprise Alliance, Inc.

“SWOP” is a registered trademark of SWOP, Inc. SWOP is a Program within IDEAlliance.

All other product and company names may be trademarks of their respective owners.

© 2009 Danny Pascale and The BabelColor Company